



To install your flag stop ring *above* your double flag pole swivel ring, completely lower flagpole all the way down, and pull out of the ground sleeve. Remove the flag from swivel ring, and carefully set aside. Lay the flagpole down onto a surface that will not scratch the pole.



Remove flag spring clip and carefully spread apart the top swivel ring with both hands and remove from flagpole.



Remove 2 screws and completely remove old style top cap.



After removing the top cap and the top swivel ring, Slide on the new stop ring. Position it above the double flag ring. Re-attach all parts to original positions.



After attaching your flag, the stop ring will work best about 2" *above* the double ring. Tighten down the white thumbscrew by hand, to hold in position.

To lower the flagpole, simply loosen the thumbscrew.